



The Kivi **Slider Hand Control** makes the acceleration and the brake controls accessible from the right of the steering wheel. The hand control presents a driving solution for drivers with partial or complete lack of functionality to the lower limbs and possibly - one or both upper limbs.

This hand control is operated by pushing the main lever toward the dashboard to apply the brakes, while sliding the thumb-operated control on the handle to accelerate.

The system is available with a plain or customisable handle that allows auxiliary functions to be programmed into the buttons to suit individual user needs.



Functional Benefits

- Increased driving control
- Versatile across vehicles
- Promotes independence

Key Features

- Easy brake and accelerator function.
- Includes a hill holder function.
- Can be made to include vehicle auxiliary functions.



6 Button Option



2 Button Option

Specifications

- Acceleration - Thumb Slide
- Brake - Push
- Right hand installation
- Operable Buttons - 2-6

